

# PHASE CHANGE MATERIALS

## PHASE

A phase is a set of states of a macroscopic physical system that have relatively uniform chemical composition and physical properties (i.e. density, crystal structure, index of refraction, etc).

## PHASE CHANGE

A phase change is the transformation of a thermodynamic system from one phase to another. The distinguishing characteristic of a phase transition is an abrupt change in one or more physical properties, in particular the heat capacity, with a small change in a thermodynamic variable such as the temperature.

## PHASE CHANGE MATERIALS

A Phase Change Material (PCM) is a substance with a high heat of fusion which, melting and solidifying at certain temperatures, is capable of storing or releasing large amounts of energy.







# DIFFERENT SOLID PHASES OF CARBON


Graphite



Diamond



# PHASE IS A FUNCTION OF TEMPERATURE



# SPECIFIC HEAT & LATENT HEAT

---

## Specific Heat

$$Q = m c \Delta T$$

Energy  
(J)

Mass  
(g)

Specific  
Heat  
Capacity  
(J/gK)

Change in  
Temperature  
(K)

---

## Latent Heat


$$Q = m L$$

Energy  
(J)


Mass  
(g)

Specific  
Latent  
Heat  
(J/g)

# PHASE CHANGE DIAGRAM




# PHASE IS A FUNCTION OF PRESSURE





# CLASSIFICATION



# DESIRABLE CHARACTERISTICS

Thermal properties	Physical properties	Chemical properties	Economic factors
Phase change temperature suitable to the desired operating range	High density	Chemical stability	Available in large quantities
High latent heat per unit mass	Low density variation during phase change	No chemical decomposition	Inexpensive
High specific heat	Little or no supercooling during freezing	Compatibility with container materials	
High thermal conductivity in both solid and liquid phases		Non-poisonous, non-inflammable and non-explosive	



# ORGANIC PCM SUBSTANCES

Compound	Melting temperature (°C)	Heat of fusion (kJ/kg)	Thermal conductivity (W/m K)	Density (kg/m <sup>3</sup> )
Paraffin C <sub>14</sub>	4.5 [1]	165 [1]	n.a.	n.a.
Paraffin C <sub>15</sub> –C <sub>16</sub>	8 [1]	153 [1]	n.a.	n.a.
Polyglycol E400	8 [4,11]	99.6 [4,11]	0.187 (liquid, 38.6 °C) [4,11] 0.185 (liquid, 69.9 °C) [11]	1125 (liquid, 25 °C) [4,11] 1228 (solid, 3 °C) [4,11]
Dimethyl-sulfoxide (DMS)	16.5 [28]	85.7 [28]	n.a.	1009 (solid and liquid) [28]
Paraffin C <sub>16</sub> –C <sub>18</sub>	20–22 [29]	152 [29]	n.a.	n.a.
Polyglycol E600	22 [4,11]	127.2 [4,11]	0.189 (liquid, 38.6 °C) [4,11] 0.187 (liquid, 67.0 °C) [11]	1126 (liquid, 25 °C) [4,11] 1232 (solid, 4 °C) [4,11]
Paraffin C <sub>13</sub> –C <sub>24</sub>	22–24 [1]	189 [1]	0.21 (solid) [1]	0.760 (liquid, 70 °C) [1] 0.900 (solid, 20 °C) [1]
1-Dodecanol	26 [9]	200 [9]	n.a.	n.a.
Paraffin C <sub>18</sub>	28 [1] 27.5 [30]	244 [1] 243.5 [30]	0.148 (liquid, 40 °C) [30] 0.15 (solid) [1] 0.358 (solid, 25 °C) [30]	0.774 (liquid, 70 °C) [1] 0.814 (solid, 20 °C) [1]
1-Tetradecanol	38 [9]	205 [9]		
Paraffin C <sub>16</sub> –C <sub>28</sub>	42–44 [1]	189 [1]	0.21 (solid) [1]	0.765 (liquid, 70 °C) [1] 0.910 (solid, 20 °C) [1]
Paraffin C <sub>20</sub> –C <sub>33</sub>	48–50 [1]	189 [1]	0.21 (solid) [1]	0.769 (liquid, 70 °C) [1] 0.912 (solid, 20 °C) [1]
Paraffin C <sub>22</sub> –C <sub>45</sub>	58–60 [1]	189 [1]	0.21 (solid) [1]	0.795 (liquid, 70 °C) [1] 0.920 (solid, 20 °C) [1]
Parffin wax	64 [4,11]	173.6 [4,11] 266 [6]	0.167 (liquid, 63.5 °C) [4,11] 0.346 (solid, 33.6 °C) [4,11]	790 (liquid, 65 °C) [4,11] 916 (solid, 24 °C) [4,11]



# ORGANIC PCM SUBSTANCES


---

## Paraffin Waxes




---

## Carboxylic Acids



---

## Esters






# INORGANIC PCM SUBSTANCES


Compound	Melting temperature (°C)	Heat of fusion (kJ/kg)	Thermal conductivity (W/m K)	Density (kg/m <sup>3</sup> )
H <sub>2</sub> O	0 [1,5]	333 [1] 334 [5]	0.612 (liquid, 20 °C) [1] 0.61 (30 °C) [5]	998 (liquid, 20 °C) [1] 996 (30 °C) [5] 917 (solid, 0 °C) [1]
Mn(NO <sub>3</sub> ) <sub>2</sub> · 6H <sub>2</sub> O	25.8 [18]	125.9 [10]	n.a.	1738 (liquid, 20 °C) [10] 1728 (liquid, 40 °C) [10] 1795 (solid, 5 °C) [10]
CaCl <sub>2</sub> · 6H <sub>2</sub> O	29 [4,11]	190.8 [4,11]	0.540 (liquid, 38.7 °C) [4,11]	1562 (liquid, 32 °C) [4,11]
	29.2 [7]	171 [1,9]	0.561 (liquid, 61.2 °C) [11]	1496 (liquid) [1]
	29.6 [6]	174.4 [12]	1.088 (solid, 23 °C) [4,11]	1802 (solid, 24 °C) [4,11]
	29.7 [1,9]	192 [6]		1710 (solid, 25 °C) [1]
	30 [8]			1634 [12]
	29–39 [12]			1620 [6]
LiNO <sub>3</sub> · 3H <sub>2</sub> O	30 [6]	296 [6]	n.a.	n.a.
Na <sub>2</sub> SO <sub>4</sub> · 10H <sub>2</sub> O	32.4 [1,7,9]	254 [1,9]	0.544 [1]	1485 (solid) [1]
	32 [13]	251.1 [12]		1458 [12]
	31–32 [12]			
Na <sub>2</sub> CO <sub>3</sub> · 10H <sub>2</sub> O	32–36 [12]	246.5 [12]	n.a.	1442 [12]
	33 [6,7]	247 [6]		
CaBr <sub>2</sub> · 6H <sub>2</sub> O	34 [4,7,11]	115.5 [4,11]	n.a.	1956 (liquid, 35 °C) [4,11] 2194 (solid, 24 °C) [4,11]

# SODIUM SULFATE DECAHYDRATE SOLUBILITY






# INORGANIC EUTECTIC PCM SUBSTANCES



INORGANIC EUTECTIC PCM SUBSTANCES


Compound	Melting temperature (°C)	Heat of fusion (kJ/kg)	Thermal conductivity (W/m K)	Density (kg/m³)
66.6% CaCl <sub>2</sub> · 6H <sub>2</sub> O + 33.3% MgCl <sub>2</sub> · 6H <sub>2</sub> O	25 [6]	127 [6]	n.a.	1590 [6]
48% CaCl <sub>2</sub> + 4.3% NaCl + 0.4% KCl + 47.3% H <sub>2</sub> O	26.8 [1,6]	188.0 [6]	n.a.	1640 [6]
47% Ca(NO <sub>3</sub> ) <sub>2</sub> · 4H <sub>2</sub> O + 33% Mg(NO <sub>3</sub> ) <sub>2</sub> · 6H <sub>2</sub> O	30 [1]	136 [1]	n.a.	n.a.
60% Na(CH <sub>3</sub> COO) · 3H <sub>2</sub> O + 40% CO(NH <sub>2</sub> ) <sub>2</sub>	31.5 [24] 30 [25]	226 [24] 200.5 [25]	n.a.	n.a.
61.5% Mg(NO <sub>3</sub> ) <sub>2</sub> · 6H <sub>2</sub> O + 38.5% NH <sub>4</sub> NO <sub>3</sub>	52 [11]	125.5 [11]	0.494 (liquid, 65.0 °C) [11] 0.515 (liquid, 88.0 °C) [11] 0.552 (solid, 36.0 °C) [11]	1515 (liquid, 65 °C) [11] 1596 (solid, 20 °C) [11]
58.7% Mg(NO <sub>3</sub> ) · 6H <sub>2</sub> O + 41.3% MgCl <sub>2</sub> · 6H <sub>2</sub> O	59 [11] 58 [6]	132.2 [11] 132 [6]	0.510 (liquid, 65.0 °C) [11] 0.565 (liquid, 85.0 °C) [11] 0.678 (solid, 38.0 °C) [11] 0.678 (solid, 53.0 °C) [11]	1550 (liquid, 50 °C) [11] 1630 (solid, 24 °C) [11]
53% Mg(NO <sub>3</sub> ) <sub>2</sub> · 6H <sub>2</sub> O + 47% Al(NO <sub>3</sub> ) <sub>2</sub> · 9H <sub>2</sub> O	61 [1]	148 [1]	n.a.	n.a.
14% LiNO <sub>3</sub> + 86% Mg(NO <sub>3</sub> ) <sub>2</sub> · 6H <sub>2</sub> O	72 [6]	>180 [6]	n.a.	1590 (liquid) [6] 1610 (solid) [6]
66.6% urea + 33.4% NH <sub>4</sub> Br	76 [11]	161.0 [11]	0.331 (liquid, 79.8 °C) [11] 0.324 (liquid, 92.5 °C) [11] 0.649 (solid, 39.0 °C) [11] 0.682 (solid, 65 °C) [11]	1440 (liquid, 85 °C) [11] 1548 (solid, 24 °C) [11]
11.8% NaF + 54.3% KF + 33.9% LiF + 1.0% NaBr	449 [26]	n.a.	n.a.	2160 (liquid) [26]

# PCM MATERIALS IN BUILDING CONSTRUCTION






# PCM VS. TRADITIONAL THERMAL MASS MATERIALS




# CONCRETE IMPREGNATED WITH PCMs



# PCMs IN WALLS







## products on the market

two companies selling  
macro-encapsulated PCM:

Dörken

Rubitherm



**maxit**  
clima 26

**GIPS-MASCHINENPUTZ MIT  
PHASENWECHSELMATERIAL**

Spezieller Innenputz mit temperaturregulierender Wirkung bei  
Raumtemperaturerhöhungen über 26 °C.



some products based on  
microcapsules (plaster,  
plasterboard, dispersion  
based plaster)

BASF: micronal




PCM – Pulver


[www.micronal.de](http://www.micronal.de)




ROOFS




# FLOORS



PCMs IN KUWAIT




# CONCLUSION





# MICRONAL® PCM THERMAL BUFFER FOR HOT DAYS





☀ The solar energy incident on the house heats the rooms up. From about 26°C onwards, the microencapsulated wax begins to melt and absorbs the excess heat.

☀ When the temperatures fall during the night, the wax becomes solid again. The warmth that is then released can be removed from the room by ventilation.

The Micronal® PCM microcapsules in SmartBoard™ are embedded in a carrier matrix of gypsum.

Encapsulated in a high strength acrylic polymer shell, the wax still retains its heat buffer function even after several decades.








# **ARCHITECTURAL PRECEDENTS**

DAVID ALLAN SOLAR HOME



# GLAUBER'S SALT CHAMBER





# TECHNISCHE UNIVERSITÄT DARMSTADT ENTRY





## SOLAR DECATHLON 2007 WINNER









# TECHNISCHE UNIVERSITÄT DARMSTADT ENTRY WALL SECTIONS



# IWAMOTO SCOTT JELLYFISH HOUSE





# **HIGH-PERFORMANCE FASHION AND SMART MATERIALS**

# THE COOL VEST



# THE COOL VEST



## CoolPack Technology | How the Vest Works

Wicking fabric carries body heat released as perspiration away from the body toward the PCM-filled packs lining the garment.

CoolPacks solidify at 59°F (15°C) and absorb body heat until saturated.


Insulation located at the exterior of the jacket minimizes absorption of ambient heat.

## CoolPack Technology | Benefits

- Helps maintain a Safe Body Core Temperature.
- Reduces chances of heat stress—heat stroke and other job site injuries.
- Increases Alertness and Production Capabilities 22%–37%.
- Decreases reaction time improves safety when operating machinery.
- Maintains a constant 59°F (15°C) temperature. Because the temperature range of the packs (59°F) is well above the typical dew point, the packs will not condense and will remain dry against the body.
- Recharges in 20 minutes and last up to 2.5 hours, based on average workload and individual metabolic rate, in a 100° F (38°C) environment, and can be recharged indefinitely.
- The typical weight of the jacket is 3 pounds for a 100°F product and 9 pounds for a 125–130°F product.

## CoolPack Technology | Users

The Cool Jackets and Cool Vest were designed for the industrial safety market. However their use has expanded to include Hazmat Teams, Foundries, under Bunker Gear and Military Flak Jackets, Costume Characters and by workers required to wear Chemical or Biological protective clothing.



# *Passive Cooling*

[www.climator.com](http://www.climator.com)